

TOOTENIMETUS	SOODUS	HIND
Solenoid lock: Abloy EL580/50 mm (lock plus spindle) Lock can be opened by handle or push button (lock plus spindle) fail unlocked setting, the electrical function is reversed. Solenoid lock Abloy EL580/50 mm (without striker plate and cable, 12-24V, low energy, spindle 57/50)	not be opened by handle when power is on	520.53 826.34 ?

